
MOBILE BAG STANDS



Stand Mobil A

Type: 4142

- Chrome-plated mobile stand with a stable design.
- Easy fastening of a bag with a rubber band. The grid at the bottom part prevents the bag from tearing.
- Wheels of Ø 80 mm.



Type: 5081

- Stand for 120 I bags. Chromed structure with a plastic lid.
- Lid opening pedal system increases the comfort when using it.
- Equipped with wheels Ø 80 mm. The grate in its bottom part prevents the bag rupture.
- 7.5 kg
- 560 x 580 x 1,020 mm
- 7 1 x 120 l






Stand for bags 120 l

Type: 7615

- Chrome frame.
- Easy bag fastening using rubber.
- Grate at the frame bottom prevents the bag from bursting.
- Solid wheels with 185 mm diameter.
- 5.5 kg





Stand for bags 120 I

Type: 7616

- Chrome frame with plastic lid.
- Easy bag fastening using rubber.
- Pedal opening.
- Grate at the frame bottom prevents the bag from bursting.
- Solid wheels with 185 mm diameter.
- 6.5 kg
- 580 x 580 x 1,020 mm



Stand for bags 120 I

Type: 7618

- Chrome frame.
- Easy bag fastening using special clips.
- Grate at the frame bottom prevents the bag from bursting.
- Rubber handles.
- Solid wheels with 80 mm diameter.
- 6.4 kg
- 600 x 620 x 1,030 mm



■ Stand for bags 2 x 120 I

Type: 7617

- Chrome frame with a plastic lid.
- Easy bag fastening using special clips.
- It can be folded up when not used (place saving).
- Grate at the frame bottom prevents the bag from bursting.
- Rubber handles.
- Solid wheels with 100 mm diameter.
- 8 kg
- 600 x 670 x 1,100 mm